

Mounting instruction: Skamol Smooth Plaster



1 Prepare SkamoEnclosure Board.



2 Mix Skamol Smooth Plaster with water according to the stated mixing ratio.



3 Apply Skamol Smooth Plaster in an even layer thickness of 1.5 to 3mm.

Application

Skamol Smooth Plaster is used as a finishing touch on the SkamoEnclosure Board.

To ensure a smooth surface, it is important that the SkamoEnclosure Board, tools, mixing baskets and water are free of dust and foreign objects of any kind.

It is not recommended to light the fireplace until the Skamol Smooth Plaster is fully hardened.

- A** Remove dust from the surface of the SkamoEnclosure Board.
- B** Apply Skamol Primer on the SkamoEnclosure Board, where Skamol Smooth Plaster is to be applied.
- C** Skamol Joint Tape is used to prevent cracking at joints.
- D** SkamoEnclosure Corner is used to protect corners.
- E** Skamol Smooth Plaster is mix in the ratio of 5,5 to 6,5L water per 15kg bag.
 - Pour 4L water into a mixing bucket
 - Stir vigorously and add the entire content of the Skamol Smooth Plaster bag (15kg)
 - Add the remaining 1.5 to 2.5L of water to the mixture until the desired consistency is achieved
 - Mix vigorously for at least 5 minutes
 - Let the mixture rest for 10 to 15 minutes and mix again until the mixture is completely softened and free of bubbles
 - After mixing, Skamol Smooth Plaster can be used for 30 to 60 minutes
- F** Skamol Smooth Plaster is applied to the SkamoEnclosure Board with a notched trowel to achieve an even layer thickness (1.5 to 3mm). The plaster is then straightened.
- G** The fireplace can be used after hardening (4 to 5 days at 20°C).

Skamol Group

Hasselager Centervej 1, 8260 Viby, Denmark
Tel.: +45 97 72 15 33

www.skamol.com